

FIG. 1




FIG. 2




FIG. 3







FIG. 4




1.0-A: Extender spacing = 6000 feet; load coils = 88 mH 1.0-B: Extender spacing = X (TBD); no load coils

Fig. 6









FIGS- AUTONOMOUS LOOPEACE FLOWERIAKT

Fig 9





FIG.9- STATE GRAPH FOR NON- AUTONOMOUS LOOPBACK






FIG. 1: - SAMPLING AND LOOPBACK COMMAND INTERPRETING

